

EXETER
EGTE

STAND	COORDINATES	STAND	COORDINATES
2	504354.04N 0032500.45W	7	504350.31N 0032507.16W
2A	504354.34N 0032500.28W	8	504349.69N 0032508.95W
3	504353.33N 0032501.92W	9	504349.42N 0032511.62W
4	504352.40N 0032503.42W	10	504348.93N 0032513.49W
5	504351.35N 0032505.05W	10L	504349.12N 0032512.46W
6	504350.34N 0032506.76W	11	504349.43N 0032511.26W

Diagram illustrating the layout of the runway and taxiway area. Key features include:

- RWY 08/26**: Runway oriented at $08/26^\circ E$.
- Taxiway C** and **Taxiway D**: Adjacent to the runway.
- South Apron**: Located near the runway.
- Storage**: Area designated for storage.
- Grass Parking**: Two designated areas for parking.
- Car Park**: Located near the storage area.
- Disused**: Areas marked as disused, indicated by dashed lines and 'X' marks.
- Change 0.20°E**: A note indicating a change in orientation.

TAXIWAY PHYSICAL CHARACTERISTICS			
TWY	SURFACE	BEARING STRENGTH	ELEVATION
Taxiways A/C/D	Asphalt	52/F/BX/U	-
Taxiway B	Concrete	54/F/BX/U	-
Taxiway E	Asphalt	16/F/BX/U	-
Taxiway F	Asphalt	10/F/BX/U	-
Taxiway G	Asphalt	40/F/BX/U	-

